



OrganoWood® Wood Cleaner

Product description

OrganoWood® Wood Cleaner is an eco-labelled superconcentrate cleaning agent.

OrganoWood Wood Cleaner is part of the OrganoWood® Wood Protection System.

Area of application

Use OrganoWood® Wood Cleaner before applying 01 Wood Protection, for maintenance washing, and general and heavy-duty cleaning of outdoor wood, for example deckings and outdoor furniture.

Maintenance washing is recommended to avoid dirt building up and growth of algae and mould. After heavy-duty cleaning of wood, re-treatment with OrganoWood® 02 Surface Protection is recommended to restore the water-repellent properties of the surface of the wood.

Eco-labelled and environmentally classified

OrganoWood® Wood Cleaner is water-based and consists of silicon minerals and natural plant substances. Wood Cleaner is eco-labelled with the Swedish Society for Nature Conservation's "Good Environmental Choice", is listed in the Swan Ecolabel Building Product Portal and can be used in Swan eco-labelled buildings. It has also been awarded environmental classification B by SundaHus and is recommended by Byggvarubedömningen and BASTA.

How to use it

Before treatment with OrganoWood® 01 Wood Protection, clean all surfaces with OrganoWood® Wood Cleaner. This also applies to new pressure-impregnated wood. One bottle is sufficient for 125 m² of pre-washing/heavy-duty cleaning or for 250 m² of maintenance washing.

1. Brush away all loose dirt from the surface of the wood. Rinse with clean water.
2. Shake well before use. Dilute according to the instructions and depending on how dirty the wood is.
3. Use a scrubbing brush, mop or similar. Avoid high-pressure washing, as this may damage the wood.
4. Rinse with water. Allow the surface to dry thoroughly.

Tip: Wash at least 24 hours before applying wood protection.

Environment, safety and shelf life

Store at 5–30°C. The product must not be exposed to frost. Shelf life in well-sealed packaging 5 years. Once poured, do not pour the product back into the packaging.

The product is not classified as environmentally hazardous waste. However, we recommend that leftover concentrated fluid is taken to a recycling centre.



The information and guidelines in this product data sheet are based on the product's safety data sheet, OrganoWood AB's test results and accumulated experience. OrganoWood AB does not take any responsibility for incorrect use of the product.

Manufacturer: OrganoClick AB, Linjalvägen 9, 187 66 Täby, Sweden. info@organoclick.com, +46 (0)8 674 00 80. www.organoclick.com

Valid from 01-01-2024. The latest version of this product data sheet is available at www.organowood.com



OrganoWood®



Maintenance

Maintenance washing with OrganoWood® Wood Cleaner is recommended. If the surface is mechanically worn, for example where people often walk or move furniture, or if the surface is washed with a strong wood cleaner or high-pressure washing (should be avoided), the wood fibres in the surface layer may be worn away and thus also the treatment. If necessary, re-treat with 02 Surface Protection. Following significant wear or heavy-duty cleaning, worn sections may also need to be re-treated with 01 Wood Protection.



The complete Wood Protection System consists of Wood Cleaner (pre-wash and maintenance wash), 01 Wood Protection (base coat) and 02 Surface Protection (top coat). 01 Wood Protection and Wood Cleaner are eco-labelled with the Swedish Society for Nature Conservation's "Good Environmental Choice".